### Voltmeter/Ammeter Changeover **Switches**

#### ■ Description

These switches are used with voltmeters or ammeters in secondary PT or CT circuits. Normally, 3-phase line voltage or phase current is measured with 3 meters provided, which requires considerable switchboard or console space. Space can be saved by using NS387 and RC310 instrument switches, since the phase current or line voltage can be read with a single meter and either VS or AS (Voltmeter or Ammeter switch). FUJI AS's are precisely and ruggedly constructed, and open circuits do not occur at the time of switch-over, so eliminating the possibility of abnormal voltage trouble. NS387 is a



blade-type switch and RC310 is a camtype. Both are compact in size and use highly dependable silver contacts. FUJI can also supply DC voltmeter type switches in addition to these for AC use.

#### **■** Ordering information Specify the following:

1. Type number

Series	Application	Туре	Ordering code	No. of contact block	Legend plate *	Handle angle	With or without Off position	Mass (kg)
NS387	AC Voltmeter	NS387/4V	AC38V4N	4	R-S · S-T · T-R	2 x 45°	Without	0.5
	AC Voltmeter	NS387/4V0	AC38V4F	4	OFF · R-S · S-T · T-R	3 x 45°	With	0.5
	DC Voltmeter	NS387/2V	AC38V2N	2	I · OFF · II	2 x 45°	With	0.43
	AC Ammeter	NS387/2M	AC38A2N	2	R·S·T	2 x 45°	Without	0.43
	AC Ammeter	NS387/2M0	AC38A2F	3	OFF·R·S·T	3 x 45°	With	0.47
	AC Ammeter	NS387/3M	AC38A3N	3	R·S·T	2 x 45°	Without	0.47
	AC Ammeter	NS387/4M	AC38A43F	4	OFF·R·S·T	3 x 45°	With	0.5
RC310	AC Voltmeter	RC310-1V	AK2R1-V32	2	R-S · S-T · T-R	2 x 45°	Without	0.22
	AC Voltmeter	RC310-1V0	AK2R1-V42	2	OFF · R-S · S-T · T-R	3 x 45°	With	0.22
	AC Ammeter AC Ammeter AC Ammeter AC Ammeter	RC310-1A2 RC310-1A20 RC310-1A3 RC310-1A30	AK2R1-A32 AK2R1-A42 AK2R1-A33 AK2R1-A43	2 2 3 3	$R \cdot S \cdot T$ $OFF \cdot R \cdot S \cdot T$ $R \cdot S \cdot T$ $OFF \cdot R \cdot S \cdot T$	2 x 45° 3 x 45° 2 x 45° 3 x 45°	Without With Without With	0.22 0.22 0.25 0.25

Note: \* For standard type legend plate. Other types can be manufactured by request.

## ■ Ratings


	<b>J</b>						
Series	Rated thermal current (A)	Making a AC (indu- Voltage (V)		ng capaci Break (A)	ty DC (indu- Voltage (V)	ctive) Make (A)	Break (A)
NS387	15	110 220 440 550	30 30 20 20	3 3 2 2	24 110 220 440	60 15 5 2.5	60 15 5 2.5
RC310	10	110 220 440 550	37.5 37.5 37.5 37.5	7.5 7.5 2.5 1.5	24 110 220 440	37.5 37.5 37.5 37.5	7.5 1.3 0.45 0.15

#### ■ Handle color (standard)


NS387: Black RC310: Black


## ■ Special spanner (for NS387)

Use this spanner for installation or replacement.



## ■ Dimensions, mm





Note: Do not remove the wires connected

No. o	of conta	ct blocks
	2	3
L	51.5	63.5


# Panel Switches NS387 and RC310


## Instrument switches

#### ■ Wiring diagrams


#### Voltmeter changeover switches

#### • NS387 series






NS387/4V0




#### • RC310 series

RC310-1V





RC310-1V0





### Ammeter changeover switches

#### • NS387 series












#### • RC310 series






## RC310-1A3



RC310-1A30



## Panel switches for industrial control switchboards

#### ■Description

NS387 control switches are used on control panels or consoles to operate H.V. circuit breakers or disconnecting switches. These switches are small in size, dependable and take up little switchboard space. Since they have a large current capacity they can be applied to many types of control circuits.

The movable blade has both an excellent contact performance and a long service life. Switches can be supplied in center spring return for momentary action and maintained versions, with 2, 3 and 4 positions. They can be fitted with H, K or R-type standard FUJI handles. The H-type is used as an ON-OFF switch to control circuit breakers or as a disconnecting switch. The K-type is mainly for regulation use and the R-type is used for controlling the power source. In addition to the standard handles key-controlled handles are also available.


Please refer to page 04/226 of this catalog for typical contact arrangements of these panel switches. We are in a position to supply many other types of switches to meet your particular application needs.


#### ■ Technical data

Insulation resistance: Over 25M $\Omega$  at 500V DC Dielectric strength: 2200V AC rms, 1 minute Durability

Mechanical: 300,000 operations

Electrical: 100,000 operations at 220V AC 5A Allowable ambient temperature: -5° to +40°C






#### ■ Ratings

Contacts	Rated	Making and breaking capac	
	thermal current (A)	DC (inductive) [W] 24V 110V 220V 440V	AC (inductive) [VA] * 110V 220V 440V 550V
Standard contact	15	1440 1650 1100 1100	3300 6600 8800 11000
Residual contact	15	1440 1650 550 220	
Non-break contact	15	720 825 550 132	

Note: \* When the operated equipment is AC electromagnet, breaking capacity is the above-mentioned 10% or less the cacpacity of the stationary state to which the electromagnet is energized.

#### **■** Dimensions, mm


## With H, I, R, K, KP, KQ, KX, KY type handle



Туре	No. of contact blocks											
	1	2	3	4	5	6	7	8	9	10		
NS387/	82	90	98	106	114	123	131	139	147	155		
NS387S/	82	90	98	106	114	123	131	139	147	155		
NS387/C	82	90	98	106	114	139	147	155	163	171		
NS387/A	82	90	98	106	114	123	131	139	147	155		
NS387/D	82	90	98	106	114	123	131	139	147	155		
Mass (kg)	0.4	0.43	0.47	0.5	0.54	0.57	0.61	0.64	0.68	0.71		

#### Special spanner

Use this spanner for installation or replacement




#### **■** Ordering information

Specify the following (See page 04/224)

- 1. Type number
- 2. Letters or symbols to be printed on legend plate
- 3. Color of rosette (if you require other color but black standard color)
- 4. Color of handle
- 5. Options if required

## **Control switches**

## **■** Type number nomenclature



Contact				Contact (varies depending on operation)				No. of combinations (varies depending on operation)				
arrange- ment			Blank	С	А	D	F	E	С	A, D	Blank	Blank (with residual contact)
1	0–10	Contacts at right angles to the operating handle (in parallel to the operating handle only in the case of the 4-position changeover type)	o o 	° × °	° <b>1</b> °°	010	o <b>.</b> †°	° + ° °	①+③+④ ≤ 10-block ③+④ ≤ 4-block	①+②+③ +④ ≤ 10-block ③+④	①+②+③ +④ ≤ 10-block ③+④	①+②+③+④ ≤ 8-block ③+④ ≤ 4-block
2	Blank, 1–10	The above contacts ① shifted clockwise by 45°	0 0 0	_	000	о <sub>П</sub> о	000	000		≤ 6-block	≤ 4-block	
3	0m– 6m	Non-interrupting contacts at right angles to the operating handle (in parallel to the operating handle only in the case of the 4-position changeover type)  Code "m" is added after the number of blocks.	₩.		<b>€</b> 1;	o → •	<b>₽</b> ;	<b>€</b> □;				
4	Blank, 1m– 6m	The above contacts ③ shifted clockwise by 45° Code "m" is added after the number of blocks.	%	<b>*</b>	% %	6 <u>L</u> 6	% %	% %				

Notes: • In each of the above contact forms, the symbol  $\square$  refers to the position of the operating handle.

• If no contacts are required, leave ② and ④ blank and enter "0" for ① and ③

#### Operation

Operation	No. of positions	Handle position	Operation angle	Code
Maintained	2	102	90°	С
	3	123	45°	Α
	4	2 <sup>3</sup> / <sub>1</sub>		D
Spring return	(3)	A OB		Blank
Spring / manual return	(3)	A O B		F
	(3)	A O B		E


### Contact

Standard contact

Non-break contact

For clockwise rotation, terminals 1, 3, and 4 are conductive before the continuity of terminals 1 and 4 is interrupted. After that, only terminals 1 and 3 are conductive.

## Residual contact



Residual contacts are used for the spring return type. The contacts will hold the state of A or B when the handle automatically returns to the center position after being turned in the A or B direction.

## **■** Operating handle

## · Combination of rosette and handle

Rosette	Handle	ype of handle (refer to 2. Shape of handle, table below)					
For NS387	For NS387	KP1	Key removable position				
	For RC310	Without micro switch: P, S, D, W	With micro switch: H, P, S, K, D, R, W				

Notes: With micro switch equipped, NS387 panel switch are provided with NS387-use rosette as standard, and with the handle for RC310-1 cam switch.

• The large handle (P, S, D, or W) for the RC310-1 is not compatible with any other handle.

## • Shape of handle

For NS387	H type	I type	K type	R type	KP type	KQ type	KX type	KY type
For RC310	H type	R type	W type	S type	P type	K type	D type	

## • Types of handle locking

Code	Center spring return type	Maintained type
Blank	In the case of the NS387, the handle can be turned after being pulled, and the handle then returns to the center position automatically when it is released. If the handle needs to be turned without being pulled, order a model with "no handle lock".  The RC310 handle can be turned without being locked.	The handle can be turned without being locked.
L1	With a handle for the RC310. The handle can be turned after being pulled, and the handle then returns to the center position automatically when it is released.	The handle can be turned after being pulled, and the handle stops at each notch when it is released.
L2	The handle can be turned without being pulled, and will return to the center position automatically when it is released. The micro switch is activated while the handle is pulled in the center position, and the switch is reset when the handle is released. The handle, however, does not turn left or right when it is pulled.	The handle can be turned after being pulled, and when it is released in any notch position, the handle will stop at that notch position. Moreover, when the handle is pulled in any notch position, the micro switch will be activated, and both the micro switch and handle will be reset when the handle is released. However, the handle cannot be switched to any other notch while it is in the pulled condition.
L3	The handle can be turned without being pulled, and will return to the center position automatically when it is released. When the handle is pulled in the left position, the lock mechanism will activate and no other notch can be selected. In that case, the handle will automatically return to the center position when it is pressed in the shaft direction.	
L4	The handle can be turned after being pulled. When it is released, the handle will automatically return to the center position in the pulled condition. The handle will return when it is pressed in the shaft direction.	-
L5	The handle can be turned without being pulled, and will return to the center position automatically when it is released. The micro switch will be activated when the handle is pulled in the center position, and the handle will return when the handle is pressed in the shaft direction.	_

Note: If a micro switch is equipped, it will be activated when the handle is pulled.

## ■ Assembled typical switches

	Type(example)	Contact arrangement	Description		
Center	NS387/2 + 0mHD		The handle can be turned after being pulled, and will return to the		
spring			center position automatically when it is released.		
return	NS387/2 + 2 + 0mHB	P 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	The handle can be turned after being pulled, and will return to the center position automatically when it is released.		
	NS387/1 + 1mHB		The handle can be turned after being pulled, and will return to the center position automatically when it is released.		
	NS387/2 + 0mS1B	6 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	RC310-1 handle, equipped with a rosette.     Add L1 for the pull-and-turn type.		
	NS387/1 + 0mS1HDL2	P 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Provided with a micro switch, RC310-1 handle, and a rosette for the NS387. The handle can be turned without being pulled, and will return to the center position automatically when it is released. The micro switch will be activated while the handle is pulled in the center position.		
	NS387/5 + 0mSBL3	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	RC310-1 handle, equipped with the NS387 rosette.     When the handle is pulled in the left position, it will be locked, and the handle will automatically return to the center position when it is pressed in the shaft direction.		
	NS387/1 + 0mS1H1BL4		<ul> <li>Equipped with a micro switch, RC310-1 handle, and a rosette for the NS387.</li> <li>The handle can be turned after being pulled, and will return to the center position automatically when it is released, but the handle remains in the pulled condition. The handle will be reset when it is pressed.</li> <li>The micro switch will be activated while the handle is pulled.</li> </ul>		
Center spring return with residual	NS387S/2 + 0mHB	P 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	_		
contact and with locking	NS387S/2 + 1+ 0mHB	0 1 2 5 6 8 0 0 0 10 13 14 17 18 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	_		
device	NS387S/2 + 2mHB		-		
Maintained 2-position	NS387/C3 + 1mKB	~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	-		
	NS387/C6 + 0mW1D	7 3 6 5 6 6 8 8 16 16 16 16 16 16 16 16 16 16 16 16 16	RC310-1 cam switch handle, equipped with a rosette.		
Maintained 3-position	NS387/A6 + 0mRB	2 01 2 5 6 8 10 13 14 17 18 21 22 10 10 10 10 10 10 10 10 10 10 10 10 10	_		
	NS387/A2 + 0mH1B		RC310-1 cam switch handle, equipped with a rosette.		
	NS387/A3 + 3 + 0mS1KDL2	2 0 0 1 2 5 6 8 1013 1417 1821 22 00 00 00 00 00 00 00 00 00 00 00 00	RC310-1 cam switch handle, equipped with the NS387 rosette.     The handle can be turned left or right without being pulled. The micro switch will be activated while the handle is pulled.		
Maintained 4-position	NS387/D4 + 1 + 1mRB	1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	_		
	NS387/D4 + 0mS1S1BL1	1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	RC310-1 cam switch handle, equipped with a rosette. The handle can be turned when it is pulled, and when it is released in a notch position, the handle will be locked in the notch. The micro switch will be activated while the handle is pulled.		
	NS387/D2 + 2 + 0mS2KDL2	7 3 7 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	RC310-1 cam switch handle, equipped with the NS387 rosette.     The handle can be turned left or right without being pulled. The micro switch will be activated while the handle is pulled.		

For other than above, contact FUJI.